

USER INSTRUCTIONS

Nomi ISB



Nomi is a popular choice as the classic entry level task chair, proven through its quality, durability and comprehensive range of variations and options.

Nomi is available with three different mechanisms, including a permanent contact back, an independent seat and back and synchronised mechanism. Nomi features three back size options, two seat sizes and height adjustable or fixed arms. The Nomi range includes a draughtsman chair.



Seat Height Adjustment



Lift lever with no weight applied to raise the seat. Lift lever and apply weight to lower the seat. This lever is found on the right hand side underneath the seat.

Seat Angle Adjustment



To adjust seat angle independently of the back, use the lever placed in the middle on the right hand side under the seat. Lift lever up to unlock seat and use weight to adjust angle before locking into preferred position. Push lever down to lock seat into position.

Back Angle Adjustment




To adjust back angle independently of the seat, lean against back cushion and use the lever placed on the right hand side under the seat towards the back of the chair. Lift lever to leave back unlocked for free float mode, which helps to encourage body movement. Push lever down to lock back position. Turn hand wheel to increase or decrease tension to compensate for body weight.

Back Height Adjustment



Lift back via integral ratchet system. Lift the back and raise to desired position. To reduce height, lift back to its highest level, (seven clicks to highest position) and the back will return to its lowest position.

Arm Options and Adjustment



- A** Fixed Arms
- B** Height Adjustable
- C** Fold Down Arms

Height: Press and hold button on the outside of arms to raise and lower arms to desired height. Release button to lock in place.

Fold Down: Press and hold button near outside base of arm, to fold arms down. Release to lock into position.

Optional Ergonomic Accessories



- A** **Headrest:** Adjust height and angle to suit. Only available for Extra High Back Nomi chairs.
- B** **Lumbar Support:** Repeatedly squeeze bulb under seat to pump up lumbar pillow in back. Gives additional lower back support. Press button to deflate.
- C** **Seat Depth:** Lift paddle labelled LIFT and use weight to move seat to preferred depth. Release paddle to lock.